

A/C WIRING



BATTERY LAST

Connect to the vehicle battery LAST.



IMPORTANT

Route and secure wires away from moving parts.

